

AZ[®] EBR Solvent AZ[®] EBR 70/30 Edge Bead Removers



GENERAL INFORMATION

 $AZ^{\mathbb{R}}$ edge bead removers are high purity, effective, low cost solvents designed for photoresist edge bead removal, coating equipment cup rinse, and wafer backside rinse. They are fully compatible with the full line of $AZ^{\mathbb{R}}$ photoresist products. $AZ^{\mathbb{R}}$ EBR 70/30 edge bead remover is formulated to provide superior performance and less offensive odour than $AZ^{\mathbb{R}}$ EBR Solvent.

 $AZ^{(R)}$ EBR 70/30 is more verstile as ist use is not only resticted to edge bead removal of Photoresist, but it is also effective for use with *AZ Aquatar* and *AZ BARLi-II*. So these Antireflective Coatings may be processed in the same track.

AZ[®] EBR Solvent and AZ[®] EBR 70/30 contain neither Cellosolve Acetate (2-etoxyethyl acetate) nor Xylene. They are made with high purity chemicals and are filtered to 0.2 micrometers absolute to assure low particulate level.

PHYSICAL and CHEMICAL PROPERTIES

	AZ [®] EBR Solvent	AZ [®] EBR 70/30
Solvent	PGMEA	PGMEA
		PGME
Max. water content [%]	0.3 %	0.3 %
Appearance	clear	clear
Flashpoint	50 °C	32 °C
Filtration	0.2 µm absolute	0.2 µm absolute

PACKAGE

AZ [®] EBR Solvent and AZ [®] EBR 70/30 are available in 5 litre bottles and in 200 litre drums. For details, please contact your AZ account manager or your local agent.

Handling Advises

Consult the Material Safety Data Sheets provided by us or your local agent!

These products are combustible liquids and should be kept away from oxidants, sparks and open flames. **Store** in sealed original containers between 0°C and 35°C.

Shelf life is limited, the **expiration date** is printed on the label of every bottle below the batch number and coded as **[day/month/year]**.

AZ EBR's are compatible with most commercially available wafer processing equipment. Recommended materials include PTFE, stainless steel and high-density poly-ethylene and -propylene.

The information contained herein is, to the best of our knowledge, true and accurate, but all recommendations are made without guarantee because the conditions of use are beyond our control. There is no implied warranty of merchantability or fitness for purpose of the product or products described here. In submitting this information, no liability is assumed or license or other rights expressed or implied given with respect to any existing or pending patent, patent application, or trademarks. The observance of all regulations and patents is the responsibility of the user.

AZ, the AZ logo, BARLi , Aquatar and Kallista are registered trademarks of Clariant AG.

Clariant GmbH Business Unit Electronic Materials Rheingaustrasse 190 D-65203 Wiesbaden Germany

Tel. +49 (611) 962-6867 Fax +49 (611) 962-9207 Clariant Corporation Business Unit Electronic Materials 70 Meister Avenue Somerville, NJ 08876-1252 USA Tel. +1 (908) 429-3500 Fax +1 (908) 429-3631 Clariant (Japan) K.K. Business Unit Electronic Materials 9F Bunkyo Green Court Center 2-28-8 Honkomagome Bunkyo-Ku Tokyo 113, Japan

Tel. +81 (3) 5977-7973 Fax +81 (3) 5977-7894 Clariant Industries Ltd. Business Unit Electronic Materials 84-7, Chungdam-dong, Kangnam-ku Seoul Republic of Korea

Tel. +82 (2) 510-8000/8442 Fax +82 (2) 514-5918



