



MICROPOSIT™ MF CD-26 DEVELOPER

Metal Ion Free - Non-Surfactant Developer

DESCRIPTION

MICROPOSIT MF CD-26 Developer is a 0.26N Surfactant Free product that offers high Photospeed and improved processing latitude for Conventional and Advanced Photoresists.

MF CD-26 is effective across various resist technologies including g/h/i line, KrF and ArF. MF CD-26 is a TMAH based Developer designed to be Metal Ion Free to avoid potential sources of Metal Ion Contamination.

MF CD-26 works well in Spray, Spray-Puddle, and Immersion processes.

FEATURES

- Low-foaming formulation
- Industry standard 0.26 Normality, surfactant free
- Improved contrast for optimal lithographic performance
- Uniform resist development with minimal bubble and residue related defects
- Effective across various resist technologies (g, g/h, i-Line, KrF, ArF)

Low Unexposed Resist Loss (URL, or Dark Field Loss)

- Outstanding edge acuity
- High differential solubility
- Improved resist profiles

Clean Efficient Development


- No scumming
- Good resolution
- Wide process latitude
- Excellent exposure throughput

Lot to Lot Consistency

- Tight product specifications
- Total systems functional testing
- Statistical quality control

MANUFACTURING PROCESS CONTROL

Multiple Step In-process Testing




***Normality Controlled +/- 0.0002N**

****Control to +/- 0.0018 TMAH**

MICROPOSIT MF CD-26 Developer

Figure 2. Normality Control Chart MF CD-26



Instructions for Use

1) Bath Make-up

MICROPOSIT MF CD-26 Developer is supplied ready to use and no bath make-up is required (there is no surfactant in the packaged product).

2) Temperature

The recommended operation is between 15°C and 20°C +/- 1°C. Photospeed does decrease as temperature increases although contrast and unexposed resist loss remains basically constant.

3) Time

Immersion: 40-60 seconds

Spray & Puddle: Varies with equipment and application, Spray is typically 20-30 secs, Puddle process is 40-60 secs.

Longer development times permit use of shorter exposure times. Shorter development times minimize Developer attack of the unexposed resist. Keeping the development constant and adjusting the exposure time as necessary to meet critical dimension requirements is recommended.

4) Agitation

Immersion: Keep agitation mild and consistent.

Spray & Puddle: Agitation is not normally required for this application, some slight rotation at slow speed for a puddle process can be applied to help the development process especially dense features.

5) Rinse

Immersion: A deionized water rinse is recommended using a cascade/overflow setup with rinsing continuing until desired resistivity is reached.

Spray & Puddle: An overlap deionized water rinse in conjunction with the developer cycle is recommended to prevent drying on the substrate surface.


6) Bath Control

Immersion: For maximum process control, replace with a fresh bath at least once per shift (24 hours, also depends on wafer count), cover when not in use.

Spray & Puddle: Not Applicable


Batch Spray: As recommended by equipment manufacturer.

Figure 3. i-Line Lithographic Performance



MICROPOSIT MF CD-26 Developer

Figure 4. KrF Lithographic Performance




Recommended Process Conditions

ARL	600Å AR3 (205°C/60 sec.)
Film Thickness	3,550Å
Softbake	130°C/60 sec.
Post-exposure Bake	115°C/60 sec.
Develop	MF [™] CD-26 (0.26N), 45 sec. Single Puddle

STORAGE

Store MICROPOSIT MF CD-26 Developer only in upright, original containers in a dry area at 10-25°C. Store away from acids, do not store in sunlight. Store away from heat and sources of ignition. Keep containers sealed when not in use, MF CD-26 Developer has a 24 month shelf life at recommended storage conditions.

Figure 5. Surface Tension Comparison (with/without Surfactant)



HANDLING PRECAUTIONS CAUTION!

MICROPOSIT MF CD-26 Developer is an alkaline corrosive liquid containing tetramethyl ammonium hydroxide. Contact with eyes, skin and mucous membranes causes irritation and burns. Handle with care, do not get in eyes, on skin or on clothing. Avoid breathing vapours or mists. Use with adequate ventilation, wash thoroughly after handling. Wear suitable PPE when handling MICROPOSIT MF CD-26 Developer.

In case of eye or skin contact, flush affected areas with plenty of water for at least 15 minutes, then seek first aid help.


Please consult the Materials Safety Data Sheet prior to use.

WASTE TREATMENT


It is the end users responsibility to verify that the disposal of MICROPOSIT MF CD-26 Developer is in accordance with federal, state, and local law. The disposal of MICROPOSIT MF CD-26 Developer should also comply with all federal, state, and local environmental laws.

MICROPOSIT MF CD-26 Developer




Circuit Board Technologies


CMP Technologies


Microelectronic Technologies


Packaging and Finishing Technologies

For locations and information please visit; <http://electronicmaterials.rohmhaas.com>

MEGAPOSIT, MICROPOSIT, MF, SPR, Rohm and Haas, and Rohm and Haas Electronic Materials are trademarks of Rohm and Haas Company, Philadelphia, PA, USA, or its affiliates.

UNITED STATES	JAPAN	ASIA	EUROPE
Marlborough, MA	Tokyo	Hong Kong	Paris, France
Tel: 800.832.6200	Tel: +81.3.5213.2910	Tel: +852.2680.6888	Tel: +33.1.40.02.54.00
Fax: 508.485.9113	Fax: +81.3.5213.2911	Fax: +852.2680.6333	Fax: +33.1.40.02.54.07

For Industrial Use Only. This information is based on our experience and is, to the best of our knowledge, true and accurate. However, since conditions for use and handling of products are beyond our control, we make no guarantee or warranty, expressed or implied, regarding the information, the use, handling, storage or possession of the products, or the applications of any process described herein or the results sought to be obtained. Nothing herein shall be construed as a recommendation to use any product in violation of any patent rights.